



- Scan the QR code on the device, then enter the password you configured, and then tap **Next**.



- Select and connect to the Wi-Fi from your router.

- Configure the name of your device, and then you can start preview.




5 Disabling DHCP

Before starting, make sure the VTO and the VTH are properly connected.


- If you have only one VTO, you can ignore this chapter.
- If you have more than one VTO, then you need to disable DHCP on the VTO that works as SIP server before connecting other VTO.

- On the VTH main interface, press and hold **Setting** until the **Password Verification** dialog box is displayed.
- Enter the VTH password, and then the advanced settings are displayed.




- Select **SIP Server**, and then the IP address displayed at **Server IP** is the IP address of the VTO that works as SIP server.

- Open the internet browser on your PC, Android phone (Android 8 or above), or iPhone (iOS 12 or above), and then enter the IP address at the address bar. The login interface is displayed.



- Enter the username and the password to login, then select **Network Setting**, and then select **OFF** at DHCP.



- Click **Save**.

6 Safeguards and Warnings

The following description is the correct application method of the device. Please read them carefully before use to prevent danger or property loss.

Operating Requirement

- Do not place and install the device in an area exposed to direct sunlight or near heat generating device.
- Do not install the device in a humid, dusty or fuliginous area.
- Please keep its horizontal installation, or install it at stable places, and prevent it from falling.
- Do not drip or splash liquids onto the device; don't put on the device anything filled with liquids, in order to prevent liquids from flowing into the device.
- Please install the device at well-ventilated places; don't block its ventilation opening.
- Use the device only within rated input and output range.
- Do not dismantle the device arbitrarily.
- Please transport, use and store the device within allowed humidity and temperature range.

About the Manual

- The Manual is for reference only, and the actual product shall prevail.
- All the designs and software are subject to change without prior written notice.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurred when using the device.
- If there is any uncertainty or controversy, please refer to our final explanation.

7 FAQ

- The device is not operating normally.**

Please reset the device and configure it again.

- How to reset the device.**

Press and hold the reset button for 10 s.

- How to enter wireless config mode.**

Press the reset button on the device, and then the device indicator light flashes with blue light.

- Device is offline.**

If the device indicator light keeps flashing with blue light, then it is offline. You need to check your network connection, and if the network connection is normal, you can reset and configure the device again.

- Connection overtime.**

- Keep the distance between the VTO, your mobile phone, and your router within 10 m.
- The configuration started before the network is properly connected.

Quick Start Guide

Villa VTO


1 Introduction

Please confirm

- 1 The device appearance is not damaged.
- 2 Confirm all the accessories according to the checklist.

Checklist:


- ◆ Villa VTO ◆ Quick start Guide ◆ Screw Package



2 Installation

Configure the device **first**, and then install it.

- 1 Drill screw holes on the mounting surface according to those on the mounting plate.
- 2 Put the expansion bolts in the screw holes.
- 3 Attach the mounting plate to the mounting surface with the screws.
- 4 Fix the VTO on the mounting plate with the screw.
- 5 Apply silica gel to gaps between the device and the wall. Liquid sodium silicate is recommended.




3 Initialization


- 1 Scan the following QR code to download and install the app .




- 2 Run the app, and then select **DOOR** on the home page.
- 3 Tap the "+" sign in the middle of the screen, and then tap **Add Device**.
- 4 Tap **Device Initialization**, and then select **AP Connection**.




- 5 Scan the QR code on the device, then tap **Next**, and then tap **Set Wi-Fi** to enable device hotspot.




- 6 Press the reset button on the device, and then the device indicator light flashes with blue light.
- 7 Go to the Wi-Fi connection interface on your phone, and then connect the Wi-Fi which name started with **VTO2111D**.



- 8 Go back to the app, and then wait until your phone is connected to the device hotspot.




- 9 Tap **Connected, next step**, and then set password for your device.



- 10 Tap **OK**, and then the device initialization is finished.

4 Adding Device

- 1 On the Add Device interface, select **AP Config Network**.



- 2 Go to the Wi-Fi connection interface on your phone, and then connect the Wi-Fi with the name started with **VTO2111D**.

- 3 Go back to the app, then wait until your phone is connected to the device hotspot, and then tap **Connected, next step**.